





Connecting cord assy
(E30-6199-05)Electric circuit module(GPS ANT)
(W02-3261-05)Mounting hardware
(J21-9867-04)Bracket
(J19-5246-04)Screw set
(N99-1713-05)DVD
(W01-1636-05)

PARTS LIST

*New Parts

- KNA-DV4100 is the same as KNA-DV3100 except the following information.
Please refer to the service manual (B53-0050-00) of KNA-DV3100.

- The DVD mechanism of KNA-DV4100 is X92-4750-00.
Please, refer to service manual X92-4750-00 (B53-0052-00) for DVD mechanism information.

- CAUTION (Repair of NAVI board)
You can not repair IC521 (GPS Receiver) and IC701 (CORE1).
If you can repair those parts please change to NAVI board assy(W02-3395-15).

Ref. No.	New	Parts No.	Description
KNA-DV4100			
201		A01-2821-02	METALLIC CABINET
204	*	A21-4437-03	DRESSING PANEL ASSY
PA1	*	A64-3493-03	PANEL ASSY
-	*	B54-4444-00	INSTALLATION MANUAL
-	*	B64-2891-00	INSTRUCTION MANUAL
-	*	H54-3231-03	ITEM CARTON CASE
232	*	W01-1636-05	DVD
VME1		X92-4750-00	DVD MECHANISM ASSY
DVD UNIT (X37-1020-03)			
IC7		DF2328VTE256Q7	MICROPROCESSOR IC